

- Fuse Value / ID
- 1 = Engine / Immobiliser +12v 20A
 - 2 = Hazards 10A
 - 3 = Lights 20A
 - 4 = Horn 10A
 - 5 = Ign Switch 10A
 - 6 = Starter Relay 20A
 - 7 = Engine / Immobiliser Ign 20A
 - 8 = Cooling Fan 20A
 - 9 = Instruments / Warning Lights 10A
 - 10 = Immobiliser Ign 10A
 - 11 = Indicators 10A
 - 12 = Brake / Reverse Lights 10A
 - 13 = Wiper / Washers 15A
 - 14 = Bike Engine Reverse Ign 15A
 - 15 = RH Side Lights / No. Plate 7.5A
 - 16 = LH Side Lights / Illumination 7.5A
 - 17 = Dipped Beam 15A
 - 18 = Main Beam 15A
 - 19 = Fog Light 7.5A
 - 20 = Spare

